

# ➤ IC Start - Electronical Starting Device

➤ The IC Start is an electronic starting device suitable for multiple sport applications. It has built in sports ready to go settings for Athletics, Swimming and Ice skating. For custom options there is a separate option where you can also load your custom start or false start sounds.

The System is delivered either with the IC/Mic, an electronical microphone or the IC/E Pistol, an electronical pistol. The system can be used with multiple different types of timekeeping system and brands of devices. IC Control Media & Sports, Swiss Timing, Finish Lynx, Qualisys, Alge and many more.

With its large 6,5" membrane speaker it offers a great sound quality not only for the start signal but also with commands, talk directly through the microphone or sounds played through the 3,5mm input. For outdoor sports and bigger events, we recommend additional external speakers that is easily plugged in to the system. Through the XLR contact it is also possible to plug in external sound systems. It is easy to modify settings our sound strength with its turn knob wheel, membrane keyboard and big LCD screen.

It has two separate Start outputs and can wirelessly trigger a third together with the ATU-X system. It also has an built in Flash as well as an external Flash output

The built in Flash that lights up the whole handle or optional external flash can be used to help hearing impariment or deafparticipants. With its many inputs and outputs, it is the perfect starting system and offer maximum flexibility for all sports!



IC/Mic and IC/E-Pistol

## ➤ Options

- Upgrade with wireless backup  
With the wireless Start Upgrade the IC Start is equipped with a Wireless 2,4 GHz or 868 MHz chip and antenna for wireless start together with the ATU-X system.
- Upgrade with Wireless Recaller controls  
With the Wireless Recallers each judge can trigger a false sound and recall the start.
- Upgrade with external loudspeakers  
For outdoor or bigger events it is a must, up to 10 pieces is possible to attach to the system.
- Upgrade with an external Flash  
For hearing impaired or deaf this option can help them to see the start signal instead of hearing it.